

Incompatible Devices – BringGo USA & CAN

Version 0.3

The following is a list of devices that are incompatible with the BringGo app:

Manufacturer	Device Name (Google Play)
ACER	Stream– a3 E120– K2 E130– K3 A200– picasso_e A211– picasso_e2 G100W– maya A110– a110 Picasso– picasso E310– c4 TD600– T603T E140– k4 DA220HQL– DA220HQL Iconia Tab A100 (VanGogh)– vangogh A701– picasso_mf E210– k5 A510– picasso_m B1-A71– B1-A71
ANYDATA	HKC P771A– P771A_WIFI ASP320Q_ANDi– ASP320Q_GSM Nextbook Next7P12– M727MC Coby MID1065– MID1065 LePanII– LePanII_wifi Insignia NS-13T001 Tablet– oracle iCraig CMP749– CMP749 HCL ME TABLET PC U2– M712MC YIFANG Nextbook NX008HI Tablet– M909NP Coby MID8065– MID8065 Carrefour CT710– M755ND Nextbook Next7D12 Tablet– M757ND Marquis Tablet– marquis_tablet Coby MID7065– MID7065 Garmin nuvi 3595– scorio Eviant MT8000– PDM829MD

	<p>HKC P774A– P774A</p> <p>Mach_Speed Trio G2 Tablet– Trio_Stealth_G2</p>
ARCHOS	<p>ARCHOS 80G9– A80S</p> <p>Gamepad– A70GP</p> <p>ARCHOS 70it2– A70it2</p> <p>ARCHOS 80 COBALT– A80CO</p> <p>ARCHOS 101G9– A101</p> <p>ARCHOS 70 Titanium– A70TI</p> <p>ARCHOS 80 TITANIUM– A80TI</p> <p>ARCHOS 101 Titanium– A101TI</p> <p>ARCHOS 97 CARBON– A97C</p> <p>Archos 101 Internet Tablet– A101S</p> <p>technika8– tsc80</p> <p>ARCHOS 80XSK– A80XSK</p> <p>ARCHOS 97 TITANIUMHD– A97TIHD</p> <p>ARCHOS 101G10– A101XS</p>
ASUS	<p>TF201– TF201</p> <p>EeePad Transformer TF101– TF101</p> <p>ASUS Transformer Pad TF300TL– TF300TL</p> <p>ASUS Tablet P1801-T– P1801-T</p> <p>ETBW11AA– ETBW11AA</p> <p>Nuvifone– a50</p> <p>TF101-WiMAX– TF101-WiMAX</p> <p>ASUS Transformer Pad TF300TG– TF300TG</p> <p>ME301T– ME301T</p> <p>Eee Pad– EeePad</p> <p>Garmin-Asus A10– a10</p> <p>ME172V– me172v</p> <p>ASUS Transformer Pad TF700T– TF700T</p> <p>Transformer TF101G– TF101G</p> <p>EeePad Slider SL101– SL101</p> <p>ASUS Transformer Pad TF300T– TF300T</p>
COMPAL	<p>A600– CAP5</p> <p>AX 8.6– penguin</p> <p>Andy– cap2</p> <p>A600– CAP6</p> <p>A8– CAP7</p> <p>COSMO DUO– CA22</p>
COOLPAD	<p>Coolpad 5820– msm7627_5820</p> <p>Coolpad W706+– msm7627_w706</p>

	Coolpad W706+ – msm7627_w706T Coolpad W708 – msm7627_w708 N930 – CP9130
DELL	Dell Streak 7 – streak7 Dell Streak 10 Pro – Streak10Pro Dell Aero – Dell_Grappa Dell Streak – qsd8250_surf
ENSPERT	Carrefour CT1010 – Carrefour ITP-S100WD – illuminus enspert_e201 – e201 ESP_E301VE – ESP_E301 MG – MGA930 vanitysmart – vanitysmart E-TAB – E-TAB
FOXCONN INTERNATIONAL HOLDINGS LIMITED	CSL Spice MI700 – mi700 Cherry-MUSN-T800 – musn-t800 WellcoM-A800 – a800 MUSN-M500 – m500 Commtiva N700 – n700 WellcoM-A89 – a89
FUJITSU	STYLISTIC M532 – mx532 STYLISTIC M350/CA2 – M350 ARROWS Tab F-05E – F05E ARROWS Tab Wi-Fi FAR70B – FAR70B ARROWS Tab LTE F-01D – blaze_tablet STYLISTIC M702 – M702 STYLISTIC MH350 – MH350
FUJITSU TOSHIBA MOBILE COMMUNICATIONS LIMITED	REGZA Phone T-01C – tg03
FUNAI ELECTRIC	ALM-001J – smdkv210
GIGABYTE	GSmart G1317 – G1317D P102g – P102g GSmart G1310 – G1310 GSmart G1317S – G1317S TB100 – TB100 GSmart G1315 – G1315 mexico – Lanix
GOOGLE	Nexus 7 – tilapia Revue – ka

	<p>Nexus 10– manta</p> <p>Nexus 7– grouper</p>
GOOGLE TV	<p>Internet TV Box– eagle</p> <p>LG TV G– smartbox</p> <p>LG Google TV– cosmo</p> <p>LG Google TV G3– eden</p> <p>Internet TV– asura</p> <p>NeoTVPrime– NeoTV</p> <p>NSZ-GS7/GX70– NSZGS7</p> <p>hisense_gx1200v– hisense_gx1200v</p> <p>VAP430– VAP430</p>
HTC	<p>HTC Flyer– express</p> <p>G1– trout</p> <p>HTC_P515E– expresskt</p> <p>Puccini– puccinilte</p> <p>Wildfire CDMA– bee</p> <p>Flyer– flyer</p> <p>Touch Viva– opal</p>
HISENSE	<p>M1101AT– TP9102</p>
HON HAI PRECISION INDUSTRY CO., LTD.	<p>PocketBook A7– EP5A_wifi</p> <p>PocketBook A10– EP10_wifi</p>
HUAWEI	<p>U8350– hwu8350</p> <p>HUAWEI MediaPad– hws7300w</p> <p>Ideos S7– qsd8k_s7</p> <p>MediaPad 10 FHD– hws10101w</p> <p>C8512– hwc8512</p> <p>HuaweiES8500– hwes8500</p> <p>MTS-SP101– hwc8511</p> <p>V858– hwu8160</p> <p>RBM2– rbm2</p> <p>A01HW– hwS7-901w</p> <p>C8600– C8600</p> <p>HUAWEI T8300– T8300</p> <p>IDEOS– U8150</p> <p>T-Mobile Pulse– u8230</p> <p>CHT8000– CHT8000</p> <p>HUAWEI-U9000– hwu9000</p> <p>U8520– hwu8520</p> <p>U8230– U8230</p> <p>IDEOS X5– msm7230</p>

	IDEOS S7 Slim – qsd8k_slim U8230 – hwu8230 C8500 – hwc8500 T-Mobile Pulse – U8100 MediaPad 10 FHD – hws10101u HUAWEI T8600 – T8600 U8500 – hwu8500 U8180 – HuaweiU8180 U8220 – U8220 TSP21 – U8110 UM840 – hwum840 Pulse – Pulse Huawei U8800-51 – hwu8800-51 C8600 – hwc8600 U8120 – U8120 U8500 – msm7225 M835 – hwm835 MediaPad 7 Lite – hws7930u M860 – M860 U8300 – U8300 U8230 – msm7201a ES8100 – hwes8100 T-Mobile Pulse – u8220 M860 – msm7625 004HW – msm7227 U8820 – hwu8820 MediaPad 7 Lite – hws7930w HUAWEI Y 220T – hwy220t
INQ MOBILE	INQ Cloud Touch – camden
JVC KENWOOD HOLDINGS, INC.	RY-AP1 – gener
KYOCERA CORPORATION	Zio – zio Zio – msm7627_kb60
KOBO	Vox – pegasus Arc – zeus
KYOCERA CORPORATION	Zio – SCP-8600 Zio – pls8600
LG	Optimus Pad – lu6900
LGE	PecanV – pecanV Optimus One – su370 LG-P925 – p925

LG-V901– v901tw
Optimus Pad– v900asia
Optimus Z– su950
Optimus Big– lu6800
LG-P920– p920
LU2300– lu2300
Optimus Pad– v909mkt
LG-P925g– p925g
LG-P993– p993
Optimus Pad– v909
Optimus Pad– l06c
Optimus Pad– v901kr
USCC-US760– envt2
LG-V900– v900aus
LG-P970– LGP970
LG-SU760– su760
Optimus Mach– LU3000
Shine Plus with Google– alohag
Optimus One– lu3700
Optimus Pad– v900
Optimus Black– ku5900
Optimus One– ku3700
KU9500– ku9500
Ally– aloha
Eve– EVE
Optimus Pad– v901ar
Optimus Mach– lu3000
Optimus Chat– hazel
Optimus Pad– v901tr
Optimus Black– lgp970
L-04C– elini
LG-LU3100– lu3100
Optimus Pad– v905r
LG-P990h– p990h
Optimus 2X– su660
Optimus LTE– i_skt
Optimus LTE– lgp935
Optimus LTE– i_u
Optimus LTE– iproj
Optimus LTE3– fx1sk

	<p>Optimus LTE Tag– lge_120_skt Optimus LTE Tag– lge_120_kt Optimus LTE– lgp93</p>
LENOVO MOBILE	<p>IdeaTab A2107A-H– a2_3g_data A2107A-H– lenovo75_a2_att_ics SmartTabII7– SmartTabII7 IdeaTab A2107A-F– a2_wifi_row IdeaTabA2109A– A2109A A30t– A30t A66t– T702T LIFETAB_S9512– LIFETAB_S9512 S61– ideatv_S61 IdeaTab K2110A-F– K2110A-F ATT, Movistar– A2107A-H ThinkPad Tablet– 18382AU Lenovo A298t– A298t Lenovo A278t– A278t MD_LIFETAB_P9516– MD_LIFETAB_P9516 Indigo– Indigo Lenovo A390e– msm7627_ea95 IdeaTabS2109A-F– S2109A A1_07– A1_07 Lenovo A288t– A288t</p>
MICROMAX	<p>P300– crane-M701C_mmx A45– tinnoes73_s8030_2g A44– tinnoes13_s7050 P275– P275</p>
MOTOROLA	<p>XOOM– stingray MOTWX435KT– Triumph XT806– qilin Glam XT800– titanium MB501– zepp Spice– sesame Milestone– A853 MZ505– graham_wifi XT800W– ttu_skt MZ505– Graham XOOM– umts_hubble MT620– TAHITI Charm– umts_basil</p>

	MB200 – morr MB520 – umts_kobe A1680 – umts_lucky XT711 – choi Motorola-XT502 – XT502 Flipout – umts_ruth XOOM 2 ME – fleming XT701 – choles Motoroi – sholest XOOM – umts_everest MZ616 – pasteur Citrus – cdma_ciena i940 – fawnridge MB508 – umts_sage Opus One – rubicon XOOM – wifi_hubble XOOM – wingray MotorolaDROID RAZR i – smi i867 – destino
NEC	D000-000001-C01 – LifeTouch_D1 D000-000002-W02 – LT-W1_2 D000-000019-002 – LTB019G LifeTouch L – LTTLA32 D000-000002-W01 – LT-W1_1 LifeTouch L – LTTLA16 D000-000002-001 – LifeTouch_W1 D000-000018-001 – LTB018 D000-000011-N – D000000011N D000-000013-101 – LTB013 D000-000019-001 – LTB019W LT-NA7 – LTNA7 D000-000010-N – D000000010N LT-NA7F – LTNA7F D000-000007-D01 – LifeTouch_D7
NIKON	COOLPIX – S800c
OPENPEAK	CIUS-7-AT – CIUS-7-AT cius – cius CIUS-7 – CIUS-7
PANASONIC CORPORATION	JT-H581VT – H581VT_A JT-B1 – B1

	SV-ME1000 – K1 JT-H580VT – H580VT_A SmartTVBox – C01AS UN-MT300 – A1 UN-W700 – F1 FZ-A1B – toughpad
PANASONIC MOBILE COMMUNICATIONS	P-08D – P-08D P-07C – laputa
PANTECH	Izar – sp33k Vega – ef12s Sirius – ef10s IS06 – jmasai PantechP4100 – pororo
PEGATRON	Android Tablet PC – TabletPC chagall – chagall Android Tablet PC – Duke3G MaxiIQ – MaxiIQ Android Tablet PC – DukeWifi Olipad – OP111
PHILIPS ELECTRONICS	Smart TV Box – HMP8100_ATV_93 Philips GoGear Connect – SA2CNTxx SA3CNT – Philips_GGC3 T8 PI7000 – Tablet_8 Philips_PI5000 – Philips_PI5000 PI3900 – T7p_Duo_93
POSITIVO	Positivo YPY7 3G – YPY_07FTA YPY 10 3G – YPY_10FTA YPY_07FTB – YPY_07FTB YPY_07STB – YPY_07STB Positivo YPY7 wifi – TB07STA YPY_10FTB – YPY_10FTB YPY_TQ7 – YPY_TQ7 YPY_10STB – YPY_10STB Positivo YPY7 wifi – YPY_07STA YPY_AB7K – YPY_AB7K Positivo YPY7 3G – TB07FTA
QUANTA CORPORATION	FT103 – FT103 OP110 – OP110 Nirvana_Tablet – Nirvana_Tablet INFINITY G NK2 – infinity_g

	MiSS– MiSS TA1013– nk1 LIFETAB_P9514– LIFETAB_P9514 VSD220– VSD220
SEMC	Xperia X10– SO-01B
SHARP	A01SH– A01SH SH8268U– SH8268U LYNX 3D SH-03C– SH03C SH8128U– msm7627 SH-05E– SH05E RW107– RW107 EB-WX1GJ/EB-W51GJ– Galapagos AQUOS PAD SHT21– SHT21 IS03– SHI03 EB-A71GJ– EB-A71GJ SHARP-ADS1– ADS1 IS01– SHI01
SK TELESYS	SK-S100– qsd8250_s1 ITP-E410W– willow ITP-R208W– rk30sdk T720– T720
SAMSUNG	Galaxy Tab 8.9– SGH-I957M Galaxy Player 5– YP-G70 SHW-M135L– SHW-M135L Galaxy Player 5.8– harrisonkrkt Galaxy Tab 7.0 Plus– SGH-T869 Galaxy Camera– gd1ltevzw Galaxy Tab– SHW-M180K Galaxy Camera– gd1ktt GT-I5800L– GT-I5800L Galaxy Tab 10.1– GT-P7500D Galaxy S– SCH-I400 SHW-M115S– SHW-M115S Galaxy Q– SGH-T589 Galaxy Player 4.2– YP-GI1 Galaxy Gio– GT-S5660B Galaxy Tab 8.9– GT-P7300 Galaxy Note 10.1– p4noteltevzw Galaxy Camera– gd1can GT-I5510M– GT-I5510M

Galaxy Note 10.1– p4notewifiww
SCH-I559– SCH-I559
Galaxy Tab– SMT-i9100
Galaxy Player 3.6– YP-GS1
GT-P7500R– GT-P7500R
Galaxy Player– YP-GB70
GT-P7320T– GT-P7320T
Galaxy Tab 10.1– SHW-M380S
Galaxy Tab II 10.1– espresso10att
Europa– GT-I5500M
Galaxy Apollo– GT-I5800
Galaxy Q– SGH-T589R
Galaxy Tab 10.1 N– GT-P7511
Galaxy Tab 7.7– SCH-I815
Galaxy Tab– GT-P1010
Galaxy Europa– GT-I5508
Galaxy Note 10.1– p4notelte
Sidekick– SGH-T839
Galaxy Camera– gd1att
Galaxy Spica– GT-I5700
GT-P7500M– GT-P7500M
Galaxy Apollo– GT-I5800D
Galaxy Tab 8.9– SHV-E140L
EK-KC120K– gd1ltekt
Galaxy Tab 10.1– SCH-I905
Galaxy Tab 8.9– SCH-P739
Galaxy Tab 10.1 v– p3
Galaxy Tab 7.7– GT-P6810
Galaxy Tab 7.0 Plus– GT-P6210
Galaxy Tab 8.9– SHV-E140K
Galaxy player 70 Plus– YP-GB70D
Galaxy Player 5.8– harrison
Galaxy Player 4.0– YP-G1
Galaxy S– GT-I9018
Galaxy Tab– SGH-T849
Europa– GT-I5503T
Galaxy Tab II 10.1– espresso10wifi
Galaxy Player 50– YP-G50
Galaxy Tab– SHW-M180W
Moment– SPH-M900

Europa– GT-I5500B
Galaxy Tab 10.1– GT-P7503
Galaxy Europa– GT-I5500
Behold II– sgh-t939
GT-P7300B– GT-P7300B
Galaxy Tab 10.1 N– GT-P7501
Galaxy Tab 8.9– GT-P7320
Galaxy Tab 10.1– SHW-M380K
Galaxy Tab 8.9– GT-P7310
Galaxy Player 4– YP-GB1
Galaxy Tab 10.1– SHW-M380W
Galaxy Tab 8.9– SHV-E140S
Galaxy Precedent– SCH-M828C
Galaxy Tab 7.7 Plus– SC-01E
Galaxy S– GT-I9008L
Galaxy Tab II 7.0– espressowifi
Galaxy Tab 8.9– SGH-I957R
Galaxy Tab 7.0 Plus– GT-P6211
Galaxy Tab 8.9– SGH-I957D
GT-P7500V– GT-P7500V
Moment– sph-m900
Galaxy Camera– gd1skt
SGH-I987– SGH-I987
IceTouch– gokey
Galaxy Tab– GT-P1013
Galaxy Tab II 10.1– espresso10vzw
Galaxy Europa– GT-I5503
DoubleTime– SGH-I857
Galaxy Tab 2 7.0– espressovzw
Galaxy Apollo– GT-I5801
Galaxy Mini– SGH-T499
Galaxy Wifi– gd1wifi
Galaxy Ace Duos– SCH-I579
Galaxy Note 10.1– p4notewifi
olleh– ik1
Behold II– SGH_T939
Galaxy Tab 7.0 Plus– SHW-M430W
SHW-M135K– SHW-M135K
VinsQ– SPH-M910
Galaxy Tab 10.1– SC-01D

Galaxy Spica– GT-I5700L
Galaxy– gt-i7500
Galaxy Note 8.0– konawifi
SHW-M480W– p4notewifiany
Transform– SPH-M920
Galaxy Tab 10.1– GT-P7500
Galaxy Indulge– SCH-R910
Galaxy Tab 8.9– SHW-M305W
Galaxy Tab II 10.1– espresso10spr
Galaxy Mini– SGH-T499Y
Galaxy S– GT-I9010
Galaxy Tab 8.9– SGH-I957
Gem– SCH-I100
Galaxy Note 10.1– p4notelteusc
Galaxy Tab 10.1– SGH-T859
Galaxy Mini– SGH-T499V
Galaxy Tab II 10.1– espresso10tmo
Europa– GT-I5500L
Galaxy Camera– gd1lteskt
Galaxy Tab 10.1– SHW-M300W
Galaxy Camera– gd1ltelgt
Acclaim– SCH-R880
Galaxy Camera– gd1
Galaxy Note 10.1– p4noteltespr
Galaxy S 4– jfltespr
Galaxy S 4– jfltetmo
Galaxy S 4– jflteatt
Galaxy S 4 Duos– ja3gchnduos
Galaxy S 4– ja3gduosctc
Galaxy S 4– jfltecan
Galaxy S 4– jfltevwz
Galaxy S 4– jflteusc
Galaxy S 4– jaltelgt
Galaxy S 4– SC-04E
Galaxy S 4– jfltecri
Galaxy S 4– jflte
Galaxy S 4– jaltesk
Galaxy S 4– jaltekt
Galaxy S 4– ja3g
Galaxy Grand– baffinlteskt

	Galaxy Grand – baffin3gduosctc Galaxy Grand Duos – baffin Galaxy Grand – baffincmcc Galaxy GRAND – baffinss Galaxy Grand – baffinltektt Galaxy Pop – superiorlteskt Galaxy Pop – SCH-i559
SANYO	Benesse – 31TL04
SONY	NW-Z1000Series – icx1216 Tablet S – nbx03 SGPT13 – txs03 Sony Tablet P – nbx02
SONY ERICSSON	Xperia X10 Mini – SonyEricssonE10i Xperia X10 – SonyEricssonSO-01B Xperia X10 Mini – E10i Xperia Play – Zeus WT18i – WT18i
SUMITOMO ELECTRIC NETWORKS	Hikari-iFrame/WDPF-703SE – dhe1100
TCT MOBILE LIMITED (ALCATEL)	ALCATEL_one_touch_908M – one_touch_908M_gsm one touch 906 – Martini One Touch 890D – one_touch_890D_gsm TCL A510 – TCL_A510 OP070 – OP070 ALCATEL_one_touch_891 – one_touch_891_gsm onetouch EVO7 – EVO7 ALCATEL_one_touch_908S – one_touch_908S_gsm One Touch 906 – one_touch_906_gsm ALCATEL_one_touch_908A – one_touch_908A_gsm ALCATEL_one_touch_913D – OT-913D ALCATEL_OT_990M – OT_990M_gsm ALCATEL_one_touch_906Y – OT-906 Vancouver_Orange – Vancouver_gsm Alcatel OT-981A – OT-981_gsm onetouch T60 – T60 Alcatel OT-981A – OT-981A_gsm Alcatel_one_touch_908F_Orange – one_touch_908F_gsm Alcatel OT-980A – OT-980A_gsm I-L1 – mercury one touch T20 – T20

	<p>Alcatel OT-980– OT-980_gsm</p> <p>ALCATEL_one_touch_890– one_touch_890_gsm</p>
TECHNICOLOR	T-Hub2 – omap4_WT3
TOSHIBA CORPORATION	<p>LT170– tostabg1</p> <p>AT200– tostab05</p> <p>DB50– tosebook01</p> <p>JP:REGZA Tablet AT570 Others:TOSHIBA AT270– tostab11BS</p> <p>JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300– tostab11BA</p> <p>Hikari-iFrame/WDPF-703TI– WDPF-703TI</p> <p>NTT docomo Photopanel 05– Pascal</p> <p>Thrive 7– tostab04</p> <p>JPN:REGZA Tablet AT830 Other countries:TOSHIBA AT330– tostab11BT</p> <p>AT100– tostab03</p>
VIZIO, INC.	VTAB1008 – VTAB1008
ZTE	<p>ZTE-T U805– U805</p> <p>Racer– mooncake</p> <p>Vodafone 945– joe</p> <p>V96A– V96A</p> <p>ZTE-C R750– r750</p> <p>ZTE-BLADE– P729C</p> <p>ZTE-C N780– banana</p> <p>ZTE U790– U790</p> <p>soft stone– P726N</p> <p>SmartTab10– V11A</p> <p>SmartTab7– V71A</p> <p>ZTE-U N721– N721</p> <p>VF945– P727A</p> <p>Android Edition Starnaute– amigo</p> <p>N720– N720</p> <p>ZTE-T U830– U830</p> <p>V66– V66</p> <p>ZTE-T T9– T9</p> <p>ZTE-U X876– P722G</p> <p>V68– V68</p> <p>ZTE U788+– z788</p> <p>D930– D930</p> <p>V55– V55</p>
IRIVER	<p>Wow TAB +– itq701</p> <p>ILT-MX100– smdkc110</p> <p>Wow(Window of the world)– itq700</p> <p>DMT580D– m805_892x</p>

UNKNOWN

Tablet PC
mw07
nuclear-a702
TOUCH90
aosbis_c7016
crane-anpei
nuclear-708h9
PMP5770D
rk2928sdk
crane-lg971
griffin
gs701b
TOUCHPAD 9
crane-a702jh
nuclear-f727
tostab12AL
nuclear-a13mid
g12refM806A2
mevlana
temp-evb
nuclear_sc3041n_ainol_novo705fc_d1
S9714
bq_edison
crane-ka009
nuclear-pfdq88c
nuclear-q7053
bq_curie
FunTab Pro
T10
nuclear-f761
nuclear-a702UNIDEN
goldfish
icx1227
bq_maxwellplus
fiber-onda978q9
lbuddy Connect
g12refM1006
nuclear-csitwo
VENUS
disco10

vigo350
zt180
STM722HZ
nuclear-f761l
tcc8900
nuclear-f721
TR719
crane-genesis
crane-a702jhorange
D01E
crane-a721
SH8168U
g12refM1005
PMP3370B
magic
A70S
CAP8
nuclear-a7028
crane-a106
U1
nuclear-anpei9
apollo-tvdevb
MW0711
crane-bc1003
g12refM805
nuclear-f900
gs702a
rk29sdk
v901
crane-m868a-tv20-1024x768
wmid
a89-plus
wwe10
SO-03E
crane-m97ft5x
LAVA_N320
maxwell
nuclear-quan
es209ra
qishang16_a10y

utv210
crane-m799
godbox
PTAB7200
nuclear-anpei8
sdkDemo
crane-MID9742-sc3052
tq03
e1011_jbl1
huashan
nuclear-Polaroid705
GT-P7510
crane-a802hw2
g08refem618
npm702
nuclear-x3
crane-bc1077
TouchPad 7
me12
crane-inet
PMP5080CPRO
SH8158U
nuclear-baili
t10s
crane-a702-lmobile
crane-m868a-tv20
anydata16_a10y
htt16_a10y
crane-evb
nuclear-v7se-sc3014n
nuclear-m876
Chairman
nuclear-mt7000
crane-a760
PMP5580C
nuclear-t53
TAB462
crane-p76ti
nuclear-107a
nuclear-anpei7

YPY
nuclear-t03
nuclear-sy777
nuclear-Q8
AMD120
taurus
miki16_a10y
npm701
STM803HC
nuclear-6225
stvmc
p7901a
msm7627_ntls
f32ref
crane-evb-v13
Coolpad_5213
g06refe3
vortex
crane-a1001Polaroid
microlab-evb
ASP320Q
htcleo
nuclear_q7053
nuclear-D50-sc3038n
nuclear-gp707pub
crane-h5
Tablet
nuclear-chip
A70H
nuclear-pub
PMP7100D3G
crane-m802h6
crane-m1003h6
PMP5097CPRO
NXM803HC
harrisonkrlgt
mercury_cdma
m801
A101IT
apollo-mele

crane-n707h6
mi350
crane-m1003h6Playtab
crane-m801h6
V1
crane-m802h6gaiban
nuclear-inet
nuclear-me107
nuclear-pfdq88
g12refM806A1SPISY
casper
etna
nuclear-pfdq88d
crane-a702
crane-aino
MID1106
android
crane-n708h6
crane-a1002hw
A1107
oppo13_gb
1234-XYZ
g06refe4